

This is a section from the

2016

Mid-Atlantic

Commercial Vegetable Production Recommendations

The manual, which is published annually, is NOT for home gardener use.

The full manual, containing recommendations specific to New Jersey, can be found on the Rutgers NJAES website in the Publications section
njaes.rutgers.edu

The label is a legally-binding contract between the user and the manufacturer.

The user must follow all rates and restrictions as per label directions.

The use of any pesticide inconsistent with the label directions is a violation of Federal law.

IRRIGATION MANAGEMENT

BASIC PRINCIPLES

Moisture management throughout the growing season is a critical factor for production of high quality vegetables. Even relatively short periods of inadequate soil moisture can adversely affect crops. Thus, supplemental irrigation is beneficial in most years, since rainfall in the mid-Atlantic region is rarely uniformly distributed, even in years with above-average precipitation.

Moisture stress has varying effects on plants according to developmental stage and type of stress. Moisture deficiencies occurring early in the crop cycle may delay maturity and reduce yields and quality. Shortages later in the season often decrease quality, as well as yields, or even result in irreversible crop damage. Over-irrigating, especially late in the season, can reduce quality and postharvest life of the crop. Table C-1 shows the periods of crop growth when an adequate supply of water is critical for high quality vegetable production.

Applying the proper amount of water at the correct time and location is critical for achieving the optimum benefits from irrigation. The crop water requirement, termed evapotranspiration or ET, is equal to the quantity of water lost from the plant (transpiration) plus that evaporated from the soil surface. ET is the most important factor for effective irrigation management. Numerous factors must be considered when estimating ET. The amount of solar radiation, which provides the energy to evaporate moisture from the soil and the plant, is the major factor. Other important factors include air temperature, wind speed, and humidity level. Different crops also have different rates of transpiration.

Instruments that measure soil moisture content are commonly used to measure changes in soil moisture and adjust irrigation schedules (see the following section "Scheduling Irrigation with Tensiometers and Resistance Meters").

Table C-1. Critical Periods of Water Needs by Crops

Crop	Most Critical Period
Asparagus	Brush (period following fern mowing)
Beans: lima	Pollination and pod development
snap	Pod enlargement
Broccoli	Head development
Cabbage	Head development
Carrots	Root enlargement
Cauliflower	Head development
Corn	Silking and tasseling, ear development
Cucumbers	Flowering and fruit development
Eggplants	Flowering and fruit development
Lettuce	Head development
Melons	Flowering and fruit development
Onions: dry	Bulb enlargement
Peas	Seed enlargement and flowering
Peppers	Flowering and fruit development
Potatoes: white	Tuber set and tuber enlargement
sweet	Root enlargement
Radishes	Root enlargement

Table continued next column

Table C-1. Critical Periods of Water Needs by Crops (cont'd)

Crop	Most Critical Period
Strawberries	Establishment, runner development, fruit enlargement
Squash: summer	Bud development and flowering
Tomatoes	Early flowering, fruit set, and enlargement
Turnips	Root enlargement

Plant factors that affect the crop water requirement are crop species and variety, canopy size and shape; leaf size, shape, wax coating and orientation; plant population density; rooting depth; and stage of growth and development of the crop. The plant canopy size and shape influences transpiration, light absorption, reflection, and the rate that water evaporates from the soil. Crops that feature a canopy with more surface area for transpiration (mature corn, potatoes, snap beans) use more water than crops which do not have an extensive canopy (immature plants, recently transplanted crops). Leaf architecture affects the transpiration rate from individual leaves. Rooting depths vary with crop species and may be affected by soil compaction or hard pans. Rooting depth determines the volume of soil from which the crop can draw water and is important when determining to what depth the soil must be wetted by irrigation. For most vegetables, effective rooting depth is approximately 12 inches.

Plant growth stage also influences susceptibility to moisture stress. Irrigation is critical when establishing newly seeded or transplanted crops. During seedling or transplant growth, especially the first 1-2 weeks, the root system is not yet established in surrounding soil. Irrigation after transplanting can significantly increase plant survival, especially when soil moisture is marginal and ET is high. Irrigation can also increase the uniformity of emergence and final stand of seeded crops. For seeded crops, reduce the rate of application and the total volume of water per application to avoid crusting (cohesion of soil particles at the surface). If crusting is present, continue to apply low rates and volume of irrigation water while seedlings are emerging. This reduces the force necessary for seeding emergence. Water use by vegetable crops increases up to full canopy and then will decrease thereafter. For warm season crops, peak water use can be as much as 0.30 inches per day in mid-summer.

Cultural practices also influence ET. Cultivation, mulching, weed growth, and method of irrigation are factors to consider. Cultivation generally increases soil evaporation but if crop roots are pruned or damaged by the cultivator, water uptake and, thus, transpiration may be reduced. Shallow cultivation may help eliminate soil crusts and, therefore, improve water infiltration from rainfall or irrigation. Weeds compete with the crop for water and increase the volume lost through transpiration. Sprinkler irrigation wets the entire crop area and, thus, has a greater evaporation loss than does trickle irrigation that wets only the area in the region of the plant root system.

Soil factors must also be considered. Soils having high levels of silt, clay, and organic matter have greater available water-holding capacities than do sandy soils or soils that are compacted (Table C-2). Available water refers to the amount of water that a plant is able to withdraw from the soil. Soils with high available water-holding capacities require less

frequent irrigation than soils with low available water-holding capacities. A greater volume of water must be applied per application on silty soils.

Table C-2. Available Water Holding Capacity Based on Soil Texture

Soil Texture	Available Water Holding Capacity (inch of water/inch depth of soil)
Coarse sand/compacted sands	0.02 - 0.06
Fine sand	0.04 - 0.09
Loamy sand	0.06 - 0.12
Sandy loam	0.11 - 0.15
Fine sandy loam/compacted loams	0.14 - 0.18
Loam and silt loam	0.17 - 0.23
Clay loam and silty clay loam	0.14 - 0.21
Silty clay and clay	0.13 - 0.18

Another soil factor that influences irrigation practices is the soil infiltration rate. Water should not be applied to soils at a rate greater than the rate at which soils can absorb water. Excessive water conditions may lead to erosion from runoff and promote disease development. Table C-3 lists the typical infiltration rates of several soils.

Table C-3. Soil Infiltration Rates Based on Soil Texture

Soil Texture	Soil Infiltration Rate (inch/hour)
Coarse sand	0.75 - 1.00
Fine sand	0.50 - 0.75
Fine sandy loam	0.35 - 0.50
Silt loam	0.25 - 0.40
Clay loam	0.10 - 0.30

There is no simple method to accurately schedule irrigations since all the above factors interact to determine actual ET. In the absence of reliable methods to estimate ET, the following factors should be kept in mind when deciding when and how much to irrigate.

1. Soils vary greatly in water-holding capacity and infiltration rate. Silt and clay soils and those high in organic matter can hold much more water than sandy soils low in organic matter.
2. Water loss from plants and the soil surface is much greater on clear, hot, windy days than on cool, overcast, humid days. During periods of hot, dry weather, when the crop is at full canopy. ET rates may reach 0.25 inch/day or higher. The evaporation component of ET can be estimated by the use of a standard evaporation pan (check with your extension office or consult on-line resources such as www.aecdatalog.com/irrigation/evappan for information on using these devices).
3. Research shows that irrigating to maintain soil moisture levels in a narrow range, just slightly below field capacity (60 to 80 percent available soil moisture), results in better crop performance than if the range is broader. Soil moisture monitoring is therefore a more accurate way to determine irrigation needs.
4. Plastic mulches reduce evaporation from the soil but also reduce the amount of water that can reach the root zone from rains. Thus, much of the natural precipitation should be discounted when scheduling irrigations for crops grown under plastic mulch.

5. In general, apply 0.25-0.75 inches of water per irrigation. This will ensure that water reaches active areas of the root zone. The exception is during early crop growth and establishment when lower rates may be appropriate.
6. If irrigation water has a high salt content (for example wells in coastal aquifers or tidal streams), excess water should be applied per irrigation to leach any salts before they are concentrated by evaporation.
7. Total weekly water needs for vegetable crops will increase up to full canopy and decrease thereafter. Irrigation rates should be adjusted accordingly. Critical crop stages such as fruiting or tuber bulking should also be considered in determining weekly irrigation rates.

DRIP (TRICKLE) IRRIGATION

Drip (or trickle) irrigation is used on a wide range of vegetable crops. Drip (or trickle) irrigation is a method of slowly applying small amounts of water directly to the plant root zone. Water is applied frequently, often daily or several times weekly, to maintain favorable soil moisture conditions. The primary advantage of drip irrigation systems is that less water is used than with sprinkler or surface irrigation systems. In many cases, one-half or less of the water applied with sprinkler or surface systems is required with drip systems. In addition, substances applied through the drip irrigation system, such as pesticides and fertilizers, are conserved along with water. Further, water applied via drip irrigation will reduce weed growth between rows.

Drip irrigation systems also have several other advantages over sprinkler and surface irrigation systems. Low flow rates and operating pressures are typical of drip systems. These characteristics lead to lower energy and equipment costs. Once in place, drip systems require little labor to operate, can be automatically controlled, and can be managed to apply precisely the amount of water needed by the crop. These factors also reduce operating costs. With most drip systems, disease and insect damage is reduced because leaves are not moistened by irrigation water. The areas between rows also remain dry, thus reducing weed growth between rows and reducing the amount of water lost to weeds. Consequently, fewer pests and pathogens are encouraged in these areas of the field. In addition, field management operations can continue during irrigation.

There are also several potential problems which are unique to drip irrigation systems. Most of these require that a higher level of management be used with drip systems than is used with other irrigation systems. Moisture dispersal throughout the soil is limited with drip systems. In most cases, a smaller soil water reserve is available to plants. Under these conditions, the potential to stress plants is greater than with other types of irrigation systems. Drip systems must be carefully managed to avoid localized moisture stress.

The equipment used in drip systems also presents potential problems and drawbacks. Drip irrigation equipment can be damaged by insects, rodents, and laborers. Pressure regulation and filtration require equipment not commonly found on sprinkler or surface systems. The drip system, including pump, headers, filters, and connections must be checked and ready to operate before planting. Failure to have the system operational could result in costly delays, poor plant survival or irregular stands, and reduced yield. Drip

systems cannot be used for frost control. Calculating the length of time required to apply a specific depth of water with a trickle irrigation system is more difficult than with sprinkler systems. Drip systems add additional cost for processing vegetables, are not adapted to drilled crops such as peas and, therefore, may not be economical for these crops.

Drip irrigation is especially effective when used with plastic film or organic mulches. Unlike sprinkler systems, trickle systems apply water to only a small portion (mulched) of the total crop acreage. Usually, a fair assumption to make is that the mulched width approximates the extent of the plant root zone and should be used to calculate system run times for most vegetables. Table C-4 has been prepared to calculate the length of time required to apply one inch of water with a drip irrigation system, based on the drip tube flow rate and the mulched width. The use of this table requires that the drip system be operated at the pressure recommended by the manufacturer.

Table C-4. Hours Required to Apply 1 Inch of water (use this table for fine-textured or heavy soils)

Drip Tube Flow Rate		Mulched Width/ Bed Width (ft)				
(gph/100 ft)	(gpm/100 ft)	2.0	2.5	3.0	3.5	4.0
8	0.13	15.5	19.5	23.5	27.0	31.0
10	0.17	12.5	16.5	18.5	22.0	25.0
12	0.20	10.5	13.0	15.5	18.0	21.0
16	0.27	8.0	10.0	11.5	13.5	15.5
18	0.30	7.0	8.5	10.5	12.0	14.0
20	0.33	6.0	8.0	9.5	11.0	12.5
24	0.40	5.0	6.5	8.0	9.0	10.5
27	0.45	4.5	6.0	7.0	8.0	9.5
30	0.50	4.0	5.0	6.0	7.0	8.5
36	0.60	3.5	4.5	5.0	6.0	7.0
40	0.67	3.0	4.0	4.5	5.5	6.0
42	0.70	3.0	4.0	4.5	5.0	6.0
48	0.80	2.5	3.0	4.0	4.5	5.0
50	0.83	2.5	3.0	4.0	4.5	5.0
54	0.90	2.5	3.0	3.5	4.0	4.5
60	1.00	2.0	2.5	3.0	3.5	4.0

On coarse-textured sandy soils, more water volume is required than for finer-textured soils. Table C-5 summarizes the length of time required to apply 1-inch of water with a drip irrigation system based on the drip tape flow rate and the crop row spacing. The use of this table requires that the drip system be operated at the pressure recommended by the manufacturer. Because water is not absorbed as much by coarse than by fine-textured soils, it moves below the plant root zone, carrying nutrients and pesticides beyond the reach of the plant roots. Table C-6 presents the maximum recommended irrigation period for drip irrigation systems. The irrigation periods listed are based on the assumption that 50 percent of the available water in the plant root zone is depleted (see next section on the use of soil moisture monitoring equipment for determining when this occurs). Soil texture directly influences the water-holding capacity of soils and, therefore, the depth reached by irrigation water.

Table C-5. Hours Required to Apply 1 Inch Water (use this table for coarse-textured or light soils)

Trickle Tube Flow Rate		Row Spacing (ft)				
(gph/100 ft)	(gpm/100 ft)	4	5	6	8	10
13.2	0.22	19	24	28.5	38.0	47.5
20.4	0.34	12.5	15.5	18.5	24.5	31.0
27.0	0.45	9.5	11.5	14.0	18.5	23.5
40.2	0.67	6.5	8.0	9.5	12.5	15.5
80.4	1.34	3.5	4.0	5.0	6.5	8.0

Table C-6. MAXIMUM APPLICATION TIMES FOR DRIP IRRIGATED VEGETABLES (use this table in combination with Table C-4 OR C-5)

Available Water Holding Capacity (inch of water / inch depth of soil) ¹	Tubing Flow Rate (gpm per 100 ft) (maximum minutes per application) ²				
	0.2	0.3	0.4	0.5	0.6
0.02	20	14	10	8	7
0.04	41	27	20	16	14
0.06	61	41	31	25	20
0.08	82	54	41	33	27
0.1	102	68	51	41	34
0.12	122	82	61	49	41
0.14	143	95	71	57	48
0.16	163	109	82	65	54
0.18	183	122	92	73	61
0.2	204	136	102	82	68
0.22	224	150	112	90	75

¹ Refer to Table C-2 for available water holding capacity based on soil texture.

² Assumes 10-inch deep root zone and irrigation at 25% soil moisture depletion.

Scheduling Irrigation with Tensiometers and Resistance Meters

Irrigation scheduling is a management practice used to determine how often to irrigate and how much water to apply with each irrigation. Irrigation duration was discussed in the previous section, and should be based on soil available water-holding capacity, soil moisture depletion level, and drip tube flow rate.

Tensiometers

Tensiometers are excellent tools for determining irrigation frequency because they measure water available in the crop root zone. Tensiometers are glass tubes with a porous tip submerged in the soil, and pressure gauge at the other end. These devices can be purchased at irrigation equipment suppliers. If handled properly, they can remain in service for many years. Tensiometers directly measure soil tension. This is also often referred to as “soil suction” or “vacuum”. Soil tension is a measure of how tightly water is held in the soil, and is measured in pressure units of centibars (cb) or kilopascals (kPa). These are different units of measurement of the same condition: soil vacuum. To convert cb to PSI, multiply by 0.15; to convert PSI to cb, multiply by 6.67.

Soil tension increases as moisture in the soil is depleted. This force also draws water out of the tensiometer through its porous tip, creating a vacuum inside the tensiometer. This negative pressure, or tension, is registered on the tensiometer vacuum gauge. The soil tension measured with tensiometers is an indirect indication of soil moisture content and can be used as an indicator of irrigation need.

Table C-7 contains guidelines for using soil tension data to schedule irrigation events. Field capacity is the moisture content at which a soil is holding the maximum amount of water it can against the force of gravity. This moisture content is reached 24 to 72 hours after a saturating rain or irrigation. Field capacity corresponds to soil tension levels ranging from 5 to 10 cb in coarse-textured soils and as high as 40 cb in fine-textured soils.

Table C-7. Irrigation Guidelines When Using Tensiometers

Soil Texture	Soil Tension (cb)	Soil Moisture Status and Irrigation Requirement
Sand, loamy sand	5 - 10	
Sandy loam, loam, silt loam	10 - 20	Soil at field capacity; no irrigation required
Clay loam, clay	20 - 40	
Sand, loamy sand	20 - 40	
Sandy loam, loam, silt loam	40 - 60	50% of available water depleted; irrigation required
Clay loam, clay	50 - 100	

The soil tension range corresponding to the time when irrigation should begin is also influenced by soil texture. In coarse-textured soils, irrigation should begin at soil tensions of 20 to 40 cb. In extremely coarse-textured soils, irrigation may be necessary at even lower tensions (Table C-7). Conversely, medium- and fine-textured soils do not need to be irrigated until soil tensions reach higher values, as shown in Table C-7. For all soil types, irrigate when a maximum of 50 percent of available water has been depleted. Lower depletion allowances may be used depending upon specific crop and management needs.

The utility of tensiometers in fine-textured soils is limited due to range of detection. When soil dries beyond the 80 cb tension level, the column of water in the tensiometer "breaks," allowing air to enter the device. After breaking tension, the device ceases to operate correctly until it is serviced. Thus, tensiometers are most practical in sandy or coarse-textured soils where normal soil tension levels are well below the point of breaking tension.

Ideally, four tensiometers per management zone should be used to account for variability in soil texture and other factors within the field being tested. Install at least one tensiometer in the area of the zone that will likely require water sooner than other areas of the field (e.g., sandier soils, higher elevations). The remaining tensiometers should be placed to inscribe a triangle within the area to be irrigated, but inside field edges. Irrigation decisions are based on the average of all the readings.

Tensiometer placement influences measured soil tension levels. Tensiometers should be placed where plant roots are actively growing. Therefore, it is appropriate to monitor soil tension 6-12 inches below the soil surface and within 6-12 inches from the plant base. If using drip irrigation, place the tensiometer axis close to the drip tape or hose and the sensor (tip) buried 6-12 inches below the soil surface. This will insure that tensiometer readings reflect moisture in the root zone and decrease when an irrigation occurs. Placement near the drip tape is even more important when growing in coarse-textured soils and on raised, mulched beds. In these situations, the bed shoulders often remain very dry and placing tensiometers there will not give an accurate measure of soil tension in the active crop root zone.

Tensiometers can also be used in other ways. Placing tensiometers at various soil depths at the same location is useful for determining whether or not an irrigation or rainfall has reached a certain depth. Placing tensiometers at various depths is also useful for determining the depth from which plants draw the most water.

Resistance Meters,

Electrical resistance meters, which determine soil water by measuring the electrical resistance between two wire grids, are embedded in a porous matrix such as gypsum, ceramics, glass fibers, or nylon cloth. These sensors are embedded in the soil. The electrical resistance of sensors varies with their water content, which in turn is dependent upon the water content of the soil in contact with them. As the soil dries, the sensor loses water and the electrical resistance increases. Therefore, resistance changes within the sensor as measured by the meter can be interpreted in terms of soil water content. New generation "matrix" sensors are more accurate and consistent than are older "gypsum" sensors. The sensors, which have stainless steel electrodes imbedded in them, are installed at desired locations and depths in the soil during the growing season. Insulated wires from each sensor are brought above the soil surface where they can be plugged into a portable meter for reading.

Resistance sensors are generally calibrated in terms of soil water tension so as to make readings applicable across soil textures. Sensors should be calibrated for each soil type. The way different commercial sensors respond to changes in soil water tension varies considerably. For this reason each manufacturer furnishes calibration curves for their own instruments and sensors. When sensor readings are expressed as soil water tension, the irrigation chart C-7 can be used as a guide.

Prepare resistance matrix sensors according to manufacturer's recommendations before installation. This normally requires soaking in water. Soaking removes air from the sensors and insures accurate meter readings. Using a soil probe or auger, bore a hole in the row slightly larger than the sensor. Make a separate hole for each sensor to desired depth. Crumble up at least 3 inches of soil removed from the hole and put it back into the hole. Pour about ½ cup of water into the hole to form a slurry of mud in the bottom. Push the sensor firmly to the bottom of the hole, forcing the slurry to envelop the sensor. A good way to do this is to use a section of ½-inch electrical conduit or pipe; slip the conduit over the lead wire and against the top of the sensor. Back fill the holes with soil 3 or 4 inches at a time, tamping firmly as the hole is filled. Drive a stake midway between the filled holes and tie the wire leads to the stake. Be sure to mark the wires in some manner so that you can identify which one is for the shallow sensor and which one is for the deeper sensor.

Install and locate resistance sensors and meters in a similar manner as for tensiometers to give accurate information of soil water depletion.

Maintaining Drip Irrigation Systems

Water is carried through plastic tubing and distributed along the tubing through orifices or devices called emitters. The emitters dissipate the pressure from the system by forcing the water exiting from an emitter through orifices, tortuous flow paths, pressure reducing flow paths, or long low paths, thus allowing a limited flow of water to be

discharged. The pressure-reducing flow path also allows the emitter diameter to remain relatively large, allowing particles that could clog an emitter to be discharged.

Insect damage to thin-walled polyethylene drip tubing or "tape" is a major problem. Ants, wireworms, earwigs, mole crickets, field crickets, grubs and other insects typically damage drip tape by chewing holes through the side walls. This damage destroys the integrity of the tape, resulting in small to massive leaks that may result in poor moisture distribution and soil erosion.

Other types of drip tape damage may be mistaken for insects. For example, rats, mice, gophers and birds can chew, gnaw or peck holes in thin walled polyethylene tapes. Damaged tape should be inspected under magnification to provide clues to the source prior to taking action to remediate the responsible agent.

To protect drip tape from insect damage, either chemical control agents or thicker walled tapes are typically used. Ant damage to drip tape is most severe in tubing having wall thicknesses of less than 15 mils (0.015 inches). In some cases, 8-10 mil products are sufficient to minimize such damage.

Although modern emitter design reduces the potential for trapping small particles, emitter clogging remains the most serious problem with trickle irrigation systems. Clogging can be attributed to physical, chemical, or biological contaminants. Filtration and occasional water treatment may both be necessary to keep trickle systems from clogging.

Bacteria can grow inside trickle irrigation tubes and form a slime that can clog emitters. Algae present in surface waters can also clog emitters. Bacteria and algae can be effectively controlled by chlorination of the trickle system. Periodic treatment **before** clogging develops can keep the system functioning efficiently. The frequency of treatment depends on the quality of the water source. Generally, two or three treatments per season is adequate.

Irrigation water containing high concentrations of iron (greater than 1 ppm) can also result in clogging problems due to types of bacteria that "feed" on dissolved (ferrous) iron. The bacteria secrete a slime called ochre that may combine with other solid particles in the trickle tubing and plug emitters. The precipitated (ferric) form of iron, known commonly as rust, can also physically clog emitters. Treating water containing iron with chlorine will oxidize the dissolved iron, causing the element to precipitate so that it can be filtered and removed from the system. **Chlorine treatment should take place upstream of filters** in order to remove the precipitated iron and microorganisms from the system. Take care when adding chlorine to trickle irrigation systems, however, since concentration at or above 30 ppm can be toxic to growing plants.

Chlorine is available in either gas, liquid, or solid forms. Chlorine gas is extremely dangerous and not recommended for agricultural purposes. Solid chlorine is available as granules or tablets containing 65 to 70 percent calcium hypochlorite. Liquid chlorine is available in many forms, including laundry bleach and postharvest wash materials. Liquid forms typically contain between 5 and 15 percent sodium hypochlorite. **Use chlorine only if the product is labeled for use in irrigation systems.**

Since chlorination is most effective at pH 6.5 to 7.5, some commercial chlorination equipment also injects buffers to maintain optimum pH for effective kill of microorganisms. This type of equipment is expensive but more effective than

simply injecting sodium hypochlorite solution. The rate of chlorine injection required is dependent on the number of microorganisms and the amount of iron in the water source, and the method of treatment being used. To remove iron from irrigation water, start by injecting 1 ppm of chlorine for each 1 ppm of iron present in the water. For iron removal, **chlorine should be injected continuously.** Adequate mixing of the water with chlorine is essential. For this reason, be certain to install the chlorine injector 50 to 100 feet upstream from filters. An elbow between the injector and the filter will also promote adequate mixing.

For treatment of algae and bacteria, a chlorine injection rate that results in the presence of 1 to 2 ppm of "free" chlorine at the end of the lateral most distant from the point of injection will ensure that the proper amount of chlorine is being injected. Free, or residual, chlorine can be tested using an inexpensive DPD (diethyl-phenylene-diamine) test kit. A swimming pool test kit can be used but it must measure free chlorine and not total chlorine.

For managing dissolved iron and microbes in the water source, one of the following basic strategies is suggested as a starting point:

For iron treatment:

- Inject liquid sodium hypochlorite continuously at a rate of 1 ppm for each 1 ppm of iron in irrigation water. In most cases, 3 to 5 ppm is sufficient.

For bacteria and algae treatment:

- Inject liquid sodium hypochlorite continuously at a rate of 5 to 10 ppm where the biological load is high.
- Inject 10 to 20 ppm during the last 30 minutes of each irrigation cycle.
- Inject 50 ppm during the last 30 minutes of irrigation cycles one to two times each month. Super chlorinate (inject at a rate of 200 to 500 ppm) once per month for the length of time required to fill the entire system with this solution and shut down the system. After 24 hours, open the laterals and flush the lines.

Chlorine can be injected using many types of fertilizer/pesticide injectors, including positive displacement injection pumps. These types of pumps are powered by gasoline or electric motors and include piston, diaphragm, gear or lobe, and roller (or peristaltic) types.

The injection rate for positive displacement injection pumps can be calculated from the following equation:

Injection rate of chlorine solution in gallons per hour

=

[(0.006) x (desired chlorine concentration in ppm) x (irrigation gallons per minute)]

÷

% chlorine in bleach or concentrate

As an example, assume household bleach (5.25% sodium hypochlorite) is being used as a chlorine solution, that a treatment level of 5 ppm of chlorine is desired, and that the trickle system has a 200-gallon-per-minute flow rate.

Injection rate of chlorine solution in gallons per hour

$$= \frac{[(0.006) \times (5 \text{ ppm}) \times (200 \text{ gallons per minute})]}{60}$$

5.25%

= 1.14 gallons chlorine per hour

Proportional injectors are also commonly used to inject chlorine. Proportional injectors are powered by the water pressure of the irrigation system and inject materials at a rate which is proportional to the irrigation system flow rate or system pressure. Injection rates are often adjustable and are usually specified as ratios, percentages, or ppm. Table C-7 lists equivalent values of these injection rate units.

For proportional injectors, the following equation can be used to calculate the required chlorine solution injection rate:

Injection rate of chlorine solution in ppm concentrate

$$= \frac{[(100) \times (\text{desired chlorine concentration in ppm})]}{\% \text{ chlorine in bleach or concentrate}}$$

As an example, assume postharvest wash material (12.5% sodium hypochlorite) is being used as a chlorine solution and that a treatment level of 10 ppm of chlorine is desired.

Injection rate of chlorine solution in ppm concentrate

$$= \frac{[(100) \times (10 \text{ ppm})]}{12.5\%}$$

= 80 ppm

It is important to note that both liquid and solid forms of chlorine will cause water pH to rise. This is critical because chlorine (sodium hypochlorite) is most effective in water at pH 6.5-7.5. If water pH is above 7.5, it must be reduced to 6.5 – 7.5 for chlorine injection to be effective as a disinfectant.

Table C-8. Equivalent Injection Proportions

Ratio	ppm	Percent
1:10,000	100	0.01
1:5,000	200	0.02
1:2,000	500	0.05
1:1,000	1,000	0.1
1:500	2,000	0.2
1:200	5,000	0.5
1:100	10,000	1
1:50	20,000	2
1:20	50,000	5
1:10	100,000	10

Important Notes.

1. **Approved backflow control valves and interlocks must be used in the injection system to prevent**

contamination of the water source. This is an absolute requirement if a public water source is being used.

2. **Chlorine concentrations above 30 ppm may cause phytotoxicity.**

Fertigation

Crops that are drip irrigated are usually fertilized during the growing phase through the irrigation system, termed fertigation. Before considering a fertilization program for mulched-drip irrigated crops, have the soil pH checked. If a liming material is needed to increase the soil pH, the material should be applied and incorporated into the soil as far ahead of mulching as practical. For most vegetables, adjust the soil pH to around 6.5 (see Table B-1).

When using drip irrigation in combination with mulch, apply the recommended amount of preplant fertilizer and incorporate 5-6 inches into the soil before laying the mulch. If equipment is available, apply the preplant fertilizer only to the soil area that will be covered by the mulch. This is more efficient than a broadcast application to the entire field.

The most efficient method of fertilizing an established mulched row crop is through a drip irrigation system that is usually installed during the mulching operation (see below). Due to the very small holes or orifices in the drip tubing, a completely soluble fertilizer or liquid solution must be used through the irrigation system. While in the past a 1-1-1 (N-P₂O₅-K₂O) ratio of completely soluble fertilizer, such as a 20-20-20 has been used successfully, in most cases, lower phosphorus concentrations are now recommended (for example 2-1-2 or 4-1-4 ratio). Solutions often are being used with no P₂O₅ (1-0-1 ratio) and this is specifically recommended where there is a high likelihood of phosphorus precipitating out of irrigation water and clogging drip emitters (hard irrigation water supplies). Including the essential micronutrients with the completely soluble N-P₂O₅-K₂O fertilizer has resulted in positive yield responses. Including boron with the completely soluble N-P₂O₅-K₂O fertilizer on sandy loam soils testing low to low-medium in boron is highly recommended for medium and high boron demand vegetable crops.

Nutrients to be applied to plants through the drip irrigation system are first completely dissolved in water to produce a concentrate. This concentrate is usually introduced into the irrigation system following filtration using a passive injector that is available from irrigation suppliers. Positive displacement pumps may also be used but be certain that internal surfaces are able to withstand corrosive fluids. Care should be taken when applying phosphorus through drip irrigation. If water sources contain high levels of calcium, calcium phosphate may precipitate which can clog drip emitters.

Fertigation Rates for Drip Irrigated Plasticulture Crops

All rates of soluble fertilizers applied through the drip irrigation system are based on crop recommendations (see individual vegetable crops in Section F). Suggested fertigation programs for common drip irrigated crops are given in Section F for the standard linear bed feet contained in an acre of that crop. This is called the Linear Bed Foot (LBF) system for fertilizer application. Rates are adjusted if crops are planted in row widths different from the standard, (more or less linear bed feet per acre). All fertigation recommendations are expressed in lb/A. Use of LBF as a

fertilizer rate assures that an appropriate rate of fertilizer will be applied, regardless of the total number LBF in the cropped area. Use of lb/A to express the fertilizer rate requires an adjustment based upon actual cropped area. The goal is to provide a specific concentration of nutrients to plant roots; or a specific amount of fertilizer within a certain volume of soil. This approach assumes that most plant roots are confined within the volume of soil comprising the bed under plastic mulch. Fertigation can occur with each irrigation event, weekly, or prior to important crop growth stages.

Calculating the fertilizer requirements for a fertigated acre based on 6 foot bed centers

a. Example for a soluble dry fertilizer to be dissolved and distributed through drip fertigation.

If 40 pounds of nitrogen (N), 40 pounds of phosphate (P₂O₅), and 40 pounds of potash (K₂O) per 7,260 linear bed feet (standard acre) per application are recommended, select a dry, completely soluble fertilizer with a 1-1-1 ratio, such as a 20-20-20. To determine the amount of 20-20-20 needed per acre, divide the percent N, P₂O₅, or K₂O contained in the fertilizer into the quantity of the respective plant nutrient needed per acre and multiply the answer by 100:

$$\begin{aligned} & [40 \text{ lbs. nitrogen needed} \\ & \div 20\% \text{ nitrogen in fertilizer}] \\ & \times 100 \\ & = 200 \text{ lbs. 20-20-20 per acre} \end{aligned}$$

b. Example for a liquid fertilizer distributed through drip.

Assume the same 40 lb N-P₂O₅-K₂O and a 6-6-6 liquid is used. If a gallon of this fertilizer weighs 10 pounds, 67 gallons of 6-6-6 liquid fertilizer per acre per application is required.

1 gal (10 lb) of 6-6-6 contains:
10 lb x .06 (6% N) = 0.6 lb N in each gallon

$$\begin{aligned} & 40 \text{ lbs. nitrogen per acre needed} \\ & \div \\ & 0.6 \text{ lb. nitrogen per gallon 6-6-6} \\ & = \\ & 67 \text{ gallons of 6-6-6 needed per acre} \end{aligned}$$

SHORT-TERM AND LONG-TERM SUBSURFACE DRIP IRRIGATION SYSTEMS

Sub-surface drip irrigation, most commonly known as SDI, is the practice of utilizing drip tape buried at depth for multi-year irrigation applications.

SDI systems offer precise efficient delivery of water, deliver nutrition or crop protection, and achieve uniform

plant production. These systems are easily automated, and can significantly decrease labor requirements. It is essential that SDI system operators be provided with adequate education to ensure they develop the necessary management skills. Water quality is a critical component of the success of an SDI system. Maintaining adequate water quality will maximize both system performance and longevity.

SDI is best addressed in two separate categories: Short-term SDI and Long-term SDI:

Short-term SDI (ST SDI) is defined by a life expectancy ranging from 3 to 10 years. However system life alone does not define Short-term SDI. These systems are typically used on mid-valued vegetable crops (for example: processed crops). ST SDI systems are commonly designed to deliver peak ET water demand to crops giving the grower greater control in meeting the crop's water needs. Typically, drip tape is installed between 3 inches and 10 inches in depth, along each crop row on the raised bed. The headers of the drip tape can be supplied with water via surface hose or permanently buried PVC pipe; the other end of the drip lateral is typically left exposed for flushing. ST SDI offers many of the advantages of surface drip irrigation without the annual expense of drip tape replacement.

Long-term SDI (LT SDI) is characterized by a life expectancy of 10 years or greater. These systems are primarily designed for commodity crops (for example: corn, cotton). The LT SDI systems are designed to efficiently deliver water to large expanses of acreage. Due to limited water availability and high crop water demand, Long-term SDI systems are not typically designed to replenish peak volume needs, but rather used to manage soil moisture profile during periods of peak water demand. Drip tape is installed from 12 inches to 18 inches in depth depending primarily on soil characteristics. Drip tape is typically centered between rows of the crop along the raised bed. The drip tape is attached on each end to permanently buried PVC pipe; with one pipe serving as the water supply and the other pipe providing the flushing function. LT SDI offers many of the advantages of surface drip irrigation, however water is applied in a manner to best economize the application while fulfilling the needs of crops.

CHEMIGATION

Chemigation is the application of any pesticide through any irrigation system and includes furrow, border, overhead and drip irrigation systems. Posting of areas to be chemigated is required when (1) any treated area is within 300 feet of sensitive areas such as residential, labor housing, businesses, hospitals, or any public zones such as schools, parks, playgrounds, etc., or (2) when the chemigated area is open to the public such as golf courses or retail greenhouses.

Prior to chemigation, first start irrigation with water to wet the root zone, then introduce the pesticide uniformly over the crop being irrigated. After chemigation, flush the irrigation system with fresh water. Do not overwater during the flush phase to retain the pesticide in the root zone. The pesticide label must allow the use of chemigation before any pesticide can be applied in the irrigation system.

Consult label for all rates and restrictions before use.

Chemigation Systems Connected to Public Water Systems

These systems must contain a functional, reduced-pressure zone, backflow preventer or the functional equivalent in the water supply line upstream from the point of pesticide introduction. The pesticide injection pipeline must contain a functional, automatic, quick-closing check valve to prevent flow of fluid back toward the injection pump.

- The pesticide injection pipeline must also contain a functional, normally closed, solenoid-operated valve located on the intake side of the injection pump connected to the system interlock to prevent fluid from being withdrawn from the supply tank when the system is either automatically or manually shut down.
- A functional interlocking control, to automatically shut off the pesticide injection pump when the water pump motor stops is also required, or in any situation where the water pressure decreases to the point where pesticide distribution is adversely affected.

Chemigation systems must use a metering pump, such as a positive displacement pump capable of being fitted with a system interlock.

Chemigation with Drip and Overhead Irrigation Systems

A safe and effective chemigation system must include the following components: a functional check valve, vacuum relief valve and low pressure drain on the irrigation pipeline to prevent water source contamination from backflow. The pesticide pipeline must contain a functional, automatic, quick-closing check valve to prevent the flow of fluid back to the injection pump.

- The pesticide injection pipeline must also contain a functional, normally closed, solenoid-operated valve located on the intake side of the injection pump and connected to the system interlock to prevent fluid from being withdrawn from the supply tank when the system is either automatically or manually shut down.
- Further, the system must contain a functional interlocking control to automatically shut off the pesticide injection pump when the water pump motor stops.
- Finally, the water pump must include a functional pressure switch which will stop the water pump when the water pressure decreases to the point where pesticide distribution is adversely affected.

Using Insecticides with Labels for Chemigation:

Note: Read and understand all chemigation instructions on label before use on any crop.

Drip/trickle Systems

azadirachtin (Aza-Direct or OLF)
 chlorantraniliprole (Coragen)
 clothianidin (Belay)
 dimethoate (Dimate)
 diazinon (Diazinon)
 dinotefuran (Venom)
 imidacloprid (Admire PRO or OLF)
 malathion (Malathion 8 Aquamul)
 oxamyl (Vydate)
 rosemary oil + peppermint oil (Ecotec)
 thiamethoxam (Platinum)
 thiamethoxam + chlorantraniliprole (Durivo)

spinosad (Entrust, SpinTor)
 spinosad + gamma-cyhalothrin (**corn only**) (Consero)
 spiromesifen (Oberon)
 spirotetramat (Movento)
 thiamethoxam (Platinum, **potato only**) (Actara)
 thiamethoxam + chlorantraniliprole (**potato only**)
 (Voliam Flexi)
 thiodicarb (Larvin)
 zeta-cypermethrin (Mustang Maxx)
 zeta-cypermethrin + bifentrin (Hero)

Overhead and Sprinkler Systems

acetamiprid (Assail)
 azadirachtin (Aza-Direct or OLF)
bacillus thuringiensis (DiPel, XenTari)
 beta-cyfluthrin (Baythroid XL)
 bifenthrin (Capture or OLF)
 bifenthrin + imidacloprid (Brigadier)
 carbaryl (Sevin or OLF)
 chlorantraniliprole (Coragen)
 chlorpyrifos (Lorsban)
 chlorpyrifos + gamma-cyhalothrin (Cobalt)
 clothianidin (Belay)
 cryolite (Kryocide)
 cyfluthrin (Renounce, Tombstone or OLF)
 deltamethrin (Battalion)
 diazinon (Diazinon)
 dimethoate (Dimate or OLF)
 dinotefuran (Venom)
 endosulfan (**potato only**) (Thionex)

Overhead and Sprinkler Systems (continued)

esfenvalerate (Asana)
 flonicamid (Beleaf)
 flubendiamide (Belt, Synapse)
 gamma-cyhalothrin (Proaxis)
 imidacloprid (Admire PRO or OLF)
 imidacloprid + beta-cyfluthrin (Leverage 2.7)
 indoxacarb (Avaunt)
 lambda-cyhalothrin (Warrior II)
 lambda-cyhalothrin + chlorantraniliprole (**potato only**)
 (Voliam Xpress)
 lambda-cyhalothrin + thiamethoxam (Endigo ZC)
 malathion (Malathion 8 Aquamul)
 methomyl (**green/bulb onions, potatoes only**) (Lannate
 LV)
 methyl parathion (PennCap-M)
 novaluron (**potatoes only**) (Rimon)
 permethrin (Pounce or OLF)
 propargite (**sweet corn, potatoes only**) (Comite)
 pymetrozine (**potato only**) (Fulfill)
 pyrethrins (PyGanic)
 spinetoram (Radiant)